

Easy Installation with the OBD2 Power Connector



The OBD2 Power Connector (fig. A) makes installation of the easiTrack GPS tracking device easy (Fig. B). There are no wires to splice. Just connect the cable to the OBD2 port of your vehicle and the other end to the easiTrack GPS tracking device. All passenger vehicles manufactured in 1997 and later have an OBD2 port.

OBD2 Cable (fig. A)



GPS Tracking Device (fig. B)



The GPS Tracking device is small at and measures: 4.1 x 3.7 x 1.1 inches

Installation steps:

Step 1) locate the vehicle's OBD2 Port. Most of the time it can be found in the foot well of the vehicle on the drivers side. (fig. C)



Step 2) Locate a covert spot for the GPS tracking device. Under or with in the dash is usually a great spot. Affix the device with zip ties and or adhesive tape. Ensure that the unit is secure and cannot move freely. Also, ensure that it is not in a spot that will get wet or be subject to the elements. Lastly, make sure that the device is facing up towards the sky (fig D). Do not mount the unit upside down. The top of the device is the side with label opposite the mounting flanges.

Fig D



Step3) Route the cable from the OBD2 connection to the Tracking device and ensure that the cable does not interfere with the operation of the vehicle, e.g. gas and brake pedals. Zip ties can be used here again to affix and route the cable to the tracking device.

Fig G

Step4) Confirm that the LED lights are flashing on the device. Double check to make sure the cable is secure along with the device. A zip tie can be placed around the connected OBD2 port and plug to secure it further and discourage any tampering. (fig G)



Step 5) after 5 to 10 minutes, the device should register on the network, provision itself to your account be tracking. You will be able to see it on the map with your login on the easitrack.net web site or mobile application for iPhone or Android.

For support or questions, please contact us at support@easitrack.com or call us 1-321-710-9996.